

## Accessory Mounts Installation:

### *Application:*

- All Co-Pilot accessory arms, satellite arms, V1 cover.
- GPS – Adjustable Tilt Mount Bracket

### *Contents of package:*

- 1 accessory mount
- BMR Hardware Kit
- Velcro Pads
- Alcohol Prep

## Installing Accessory Mounts:

- 1 – Raise the windscreen to the maximum elevation to avoid any damage from your tools.
- 2 – Attach the left or right or centered accessory mount to the Co-Pilot using BMR's hardware mounting kit. Screw the mount down tightly thru threaded rivet nut sets positioned on the Co-Pilot shelf left, right and center.

## Mounting the V1 Valentine Cover:

- 1 – The V1 cover is designed to attach to the left or right **Medium** Accessory Arm.
- 2 – First attach the arm as described above.
- 3 – The Valentine radar detector must be placed center on the **Medium** Arm with Velcro set.
- 4 – Undo the front screw of the accessory arm.
- 5 – Clip the outside of the cover under the outside edge of the accessory arm. There should be a small gap between the V1 cover and the accessory arm at the screw hole.
- 6 – Screw the cover down tightly with the long 5 mm Allen screw provided.

## Mounting Hardware options:

BMR Products has supplied a mounting hardware kit designed with high quality marine grade Stainless Steel and versatility in how you want the hardware appearance to be. You have the option of using neoprene stainless steel washers with stainless steel screws to show an attractive contrast with bright polished stainless steel and the matte black powder coat finish. Optionally you may want to cover your Stainless Steel screws with the very cool "Black Caps". This option hides the screws and makes the opportunity for theft more difficult.

**Option:** Push screw thru neoprene S.S. washer and install. (Screw down tightly)

**Option:** Push screw thru plastic "Black Cap" and install. (Screw down tightly) After the screw is tightened, press the hinged cap over the screw head firmly until it snaps closed. To open the "Black Cap" to remove screw, simply place a thin bladed object (thin flat screw driver or a knife blade) under bottom edge of cap and gently pry up to pop it open. If you change your mind over "Black Cap or S.S. washer you can remove either one by simply unscrewing it while holding cap or washer firmly between index finger and thumb.