

Accessory Arm Installation

Application:

- All Co-Pilot accessory arms, satellite arms, V1 cover.

Contents of package:

- 1 x accessory arm
- 2 x BMW Torx or Allen screws

Tools needed other than those found in the BMW toolkit:

- None

Mounting the Accessory arm:

1. Raise the windscreen to the maximum elevation to avoid any damage from your tools.
2. Attach the left or right accessory shelf to the Co-Pilot using the BMW Torx or Allen screws supplied.

Mounting the V1 Valentine Cover:

1. The V1 cover is designed to attach to the left or right **Medium** Accessory Arm.
2. First attach the arm as described above.
3. Assemble and mount the Valentine radar detector as you would without the cover. *Do not attempt to attach the cover then squeeze the Valentine into the recess.*
4. Undo the front screw of the accessory arm.
5. Clip the outside of the cover under the outside edge of the accessory arm. There should be a small gap between the V1 cover and the accessory arm at the screw hole – this will provide some gripping pressure to the Valentine unit.
6. Screw the inside of the cover down with the long Torx/Allen provided.