

SP2610 SunVisor Installation

Contents of package:

- 1 x SP2610 SunVisor
- 1 x strip of self-adhesive DualLock
- 1 x alcohol swab

Tools needed other than those found in the BMW toolkit:

- None

Note: This product is designed to fit on the Garmin 2610 StreetPilot GPS unit.

Positioning the DualLock strip:

- Ensure the top & side surfaces of the GPS unit are clean.
- Note the join along the top of the GPS separating the front from the rear.
- Using the join as a guide, center the DualLock strip above the GPS and in front of the join.
- Attach the DualLock strip along the top before folding it down each side.

Attaching the SunVisor:

- Position the SunVisor over the GPS.
- Adjust the SunVisor to the best position then press down and lock the top surface, allowing the DualLock strips to bind. Press and lock the sides to ensure a snug fit.



(SP3 and StreetPilot-III shown here)