

SP3 SunVisor Installation

Contents of package:

- 1 x SP3 SunVisor
- 1 x strip of self-adhesive DualLock
- 1 x alcohol swab

Tools needed other than those found in the BMW toolkit:

- None

Note: This product is designed to fit on the Garmin StreetPilot III™ or BMW Navigator GPS unit.

Positioning the DualLock strip:

1. Ensure the top & side surfaces of the GPS unit are clean and free from grease.
2. Note the join along the top of the GPS separating the front from the rear.
3. Using the join as a guide, center the DualLock strip above the GPS and in front of the join.
4. Attach the DualLock strip along the top before folding it down each side.

Attaching the SunVisor:

1. Position the SunVisor over the GPS.
2. Adjust the SunVisor to the best position then press the top surface of the DualLock in place. Press the sides and top to ensure a snug fit.

