

660 – 665 Zumo SunVisor

Contents of Package:

- 1 – 660 – 665 Zumo SunVisor
- 2 – Stainless Steel Washers

Ensure the motorcycle is placed on the center stand (Please read entire Installation document before proceeding)

This SunVisor is designed to mount to the “Adjustable Tilt Mount” with Zumo power- audio cradle already attached to Adjustable Tilt Mount. Your Zumo 660 - 665 can be removed leaving SunVisor in place.



Remove top 2 nuts



Slide on 2 large washers.



Tighten SunVisor flush with top of Zumo.

For easier Zumo removal, you can adjust SunVisor fit to top of power-audio cradle from flush mount to 1/8 inch max.



Pop your Zumo GPS into place. Bottom first, then top. You will have to lift the front edge of SunVisor about 1/2 inch as you snap your Zumo into place. Use the same technique with taking off your Zumo. Lift front edge of SunVisor slightly to pop off your Zumo 660 – 665.