

---

## K1200LT XM Satellite Antenna Mount Installation

### Contents of package:

- XM Satellite Antenna Mount
- 2 x industrial cable ties
- 1 x rubber grommet

### Tools needed other than those found in the BMW toolkit:

- None

### Notes:

1. We do not recommend that you remove the motorcycle FM antenna base plate for any reason. Antenna tuning may be affected.
2. Do not cut the XM antenna cables. There is a cavity directly above the rear tail light under the flat black plastic dust cover that will accommodate the excess length of cable. The balance of the cable with the plugs can be routed alongside the FM antenna cable to the front of the bike to where the XM header unit is located.

### Positioning the XMS Antenna Mount:

1. Place the magnetized XM antenna on the mount before attaching the mount to the motorcycle.



2. Thread the antenna cables through the rubber grommet located at the center of the bracket (or in the case of the Delphi unit, up the slit in the plate and into the sliced grommet). Prepare to thread these cables along the underside of the bracket to follow the motorcycle FM antenna cable into the body of the motorcycle.
3. Position the XM Antenna Mount up against the underside of the FM antenna, adjusting as necessary to locate the 4 base plate screw heads within the 4 holes provided in the mounting bracket. The bracket should be flush against the FM antenna base plate.

### Securing the XMS Antenna Mount:

1. Thread each of the 2 cable ties provided through the small slots provided for them, up and over the FM antenna base, securing the Bracket and the XM cables snugly to the underside of the FM antenna base.