
K1200LT DLM-M/L Mirror Mount Installation

Contents of package:

- 1 (pair) Driving Lamp Mounts (long or standard bracket)
- 4 medium/small Torx screws
- 4 lock nuts
- 4 washers

Tools needed other than those found in the BMW toolkit:

- None

Mounting the DLM Brackets:

1. Remove each side mirror.
2. Remove the bottom rear mirror mounting stud and the lower Torx screw.
3. Mount each K12DLM unit on the appropriate side.
4. Replace the mirrors.
5. Use the complimentary Torx screws , washers and lock-nuts provided in the package to mount your driving lamps.

