

K1200LT DLM-C Bracket Installation

Contents of package:

- 1 (pair) DLM brackets
- 4 medium Torx screws
- 4 lock nuts
- 4 washers

Tools needed other than those found in the BMW toolkit:

- None



Mounting the DLM Brackets:

1. * Remove each upper side-panel from the motorcycle, placing them carefully on some protective surface.
2. Remove the top two Torx screws from the upper front leading edge of interior of each side-panel.
3. Mount each K12DLM unit on a side-panel using these existing two Torx screws.
4. If you choose to drill mounting holes for your driving lamps, you may wish to bolt through the horizontal surface of the plastic deflector for added rigidity.
5. Use the 4 complimentary Torx screws, washers and lock nuts included in the package to mount your driving lamps.

* Notes on removing the side panels:

1. Pop off the side mirror
2. Remove the wind deflector (3 screws)
3. Remove the indicator lens - unplug the bulb
4. Remove the crash bar cover - 1 screw at rear (just in front of your foot); 1 screw underneath at front; 1 screw underneath in center; 2 allen screws securing black trim underneath;
5. Open glove box; remove 2 allen screws securing small center cover (in front of seat).
6. Remove this cover (slide down/back and lift out).
7. Raise the driver seat.
8. Working clockwise on left hand side of bike remove the following screws:
 - a. screw immediately under rider seat on top rim
 - b. screw in center (was under cover plate)
 - c. screw 'in' glove compartment
 - d. screw under mirror
 - e. screws in indicator light recess (x2)
 - f. screws along bottom (x3)
9. The rear of the panel is plugged into a large rubber grommet (directly under the rider seat mid-panel) - unplug this gently
10. Holding the front and the rear of the panel gently wiggle it UPWARDS first then out towards you. There is a small locator tab on the side panel next to the glove compartment that is used as a locator in a slot in the radio cover. Be sure not to bend this when replacing the cover.

The install is just the reverse of the above, taking care not to bend the locator tab.