

K1200LT Flatbed Installation

Contents of Package:

- 1 x Flatbed Luggage Rack
- 2 x Flatbed mounting brackets
- 2 x wide flange Allen mounting bracket bolts
- 2 x thumbscrews (located on Flatbed)

Tools you will need other than those found in the BMW toolkit:

- wirecutters or clippers
- small flat file, chisel or Dremel tool

Note: this will require the removal of the passenger seat

Ensure the motorcycle is placed on the center stand.

Installing the Mounting Brackets:



1. Remove passenger seat. (Take care with the heated seat plug if installed)



2. Snip the molded plastic away from the side-case mount supports.
3. Remove side-case mounting bolt and dremel or file smooth the snipped area.



4. Using the new wide-flange Allen bolt provided, install and secure the left and right Flatbed support brackets where the side-case mounting bolts have just been removed.
5. Re-install passenger seat.

Mounting the Flatbed:

1. Open side-cases.
2. Remove the thumbscrews from the Flatbed.



3. Slide front tongue (on the curved section) between rider/passenger seats.



4. Slide the Flatbed support brackets between bike bracket and seat.
5. Tighten thumbscrews.
6. *Load and Go!*

Removing the Flatbed:

This is the reversal of the mounting procedure. The brackets that are mounted to the bike remain in place. To avoid misplacement, we recommend that the thumbscrews be attached to the Flatbed when stored away.

Footnote:

We would appreciate your feedback on our product, especially if you include a picture or two of you on your travels, the FlatBed being highly visible of course! Send these to feedback@bmrproducts.com

Ride Safe.