

## K1200LT Rear Swing arm Reaction Link Installation

### Contents of Package:

- 1 set (2 pieces) Swing Arm Reaction Link

### Tools you will need other than those found in the BMW toolkit:

- 16mm socket or wrench (preferably both)

**Ensure the motorcycle is placed on the center stand.**

### Installing the Swing Arm Link:

1. With the rear wheel above the ground it is useful to place a small block to brace the wheel in position – removing the reaction link will allow it to sag.
2. Remove the 16mm bolts retaining the BMW reaction link at both the rear wheel drive and frame ends, and remove the link arms.
3. Assemble the BMR reaction links using the same 16mm bolts.

### Tightening torques:

Reaction link to rear wheel drive	43 Nm
Reaction link to frame	43 Nm

