

---

## K12 Side Case Trim Installation

### *Contents of package:*

- 2 x long trim sections
- 2 x short trim sections
- 2 x alcohol swabs

### *Tools needed other than those found in the BMW toolkit:*

- None

### **Mounting the trim:**

1. Clean the chrome edging with the alcohol swab making sure that it is clean and grease free.
2. Align the trim sections on the bike before peeling the backing off the trim sections to make sure that you're getting each piece on the correct side.
3. Pre-bend the small rear pieces – **try not to apply the strips in cold weather.**
4. Peel the backing off the trim sections and press firmly to the chrome trim.

