SP3 Tilt Mount Installation

Contents of package:

- 1 x Garmin StreetPilot-III Tilt Mount
- 2 x long Torx or Allen screws

Tools needed other than those found in the BMW toolkit:

- None

Note:

When loosening the Garmin Tilt Mount unit, do not remove the small retaining screw on the slider, nor remove the slider from the rail. If you do, you stand a good chance of losing the small spring that is contained in the slider button!

Mounting:

- Place the Tilt Mount bracket over the center pair of holes that are pre-drilled in the BMR Co-Pilot mount.
- Attach the tilt mount using the 2 standard (medium) BMW Torx (or Allen) bolts supplied.

Adjustment:

- With the GPS mounted in the bracket, position the angle of the mount to suit and finger-tighten the thumb-screw.
- Remove the GPS without adjusting the mount, and using a pair of broad-nose pliers, tighten the thumb-screw firmly. (There is a tendency for this screw to vibrate loose and then wear down the locking splines).
- To further prevent vibration, a strip of self-adhesive foam rubber door sealer (1¼" wide x ½" thick) cut the length of the GPS and attached to the Co-Pilot directly under the GPS, can be used. The GPS can then be lowered on the slider until pressure is applied to the foam strip.